



Tape template to outside.
Remove lower shock bolt
and rotate shock out of
way. Drill (2) 1/4" holes.

